

# SGR Installation-American Standard Mounting Hardware



1. Clean shaft



4. Drill hole 1/4" deep

## Installation Tools:

Drill

#36 drill bit

Hammer

Transfer punch

6-32 tap

Allen wrench-7/64"



2. Center SGR on the shaft to ensure fiber contact.



5. Tap hole



3. Mark drill point using transfer punch and mounting clip.



6. Secure SGR with 2 or 3 mounting clips and hardware.

Shaft must be clean & free of any coatings, paint, or other nonconductive material.

